



# FOR SERIES 1 ATTACHMENTS

## STALL TYPE INSTALLATION 5/64 WRENCH TIP



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	LENGTH OF SOCKET				
			1/4	1/2	3/4	1	1 1/2
5/64	7/32	SOCKET ACCESSORY ASSEMBLY	12552	12553	12554	12555	12556
		SOCKET	12517	12518	12519	12520	12521
		JIFFY TIP 5/64 STALL	12577	12578	12579	12580	12581
	1/4	SOCKET ACCESSORY ASSEMBLY	12557	12558	12559	12560	12561
		SOCKET	12522	12523	12524	12525	12526
		JIFFY TIP 5/64 STALL	12577	12578	12579	12580	12581
	9/32	SOCKET ACCESSORY ASSEMBLY	12562	12563	12564	12565	12566
		SOCKET	12527	12528	12529	12530	12531
		JIFFY TIP 5/64 STALL	12577	12578	12579	12580	12581
	5/16	SOCKET ACCESSORY ASSEMBLY	12567	12568	12569	12570	12571
		SOCKET	12532	12533	12534	12535	12536
		JIFFY TIP 5/64 STALL	12577	12578	12579	12580	12581
	11/32	SOCKET ACCESSORY ASSEMBLY	12572	12573	12574	12575	12576
		SOCKET	12537	12538	12539	12540	12541
		JIFFY TIP 5/64 STALL	12577	12578	12579	12580	12581