



# FOR SERIES 2 ATTACHMENTS

## STALL TYPE INSTALLATION 5/64 WRENCH TIP



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	1/4	1/2	1	1 1/2	2	2 1/2	3
5/64	7/32	SOCKET ACCESSORY ASSEMBLY	12725	12726	12727	12728	12729	12730	12731
		SOCKET	12679	12680	12681	12682	12683	12684	12685
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780
	1/4	SOCKET ACCESSORY ASSEMBLY	12732	12733	12734	12735	12736	12737	12738
		SOCKET	12686	12687	14446	12688	12689	12690	12691
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780
	9/32	SOCKET ACCESSORY ASSEMBLY	12739	12740	12741	12742	12743	12744	12745
		SOCKET	12692	12693	12694	12695	12696	12697	12698
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780
	5/16	SOCKET ACCESSORY ASSEMBLY	12746	12747	12748	12749	12750	12751	12752
		SOCKET	12699	12700	14445	12701	12702	12703	12704
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780
	11/32	SOCKET ACCESSORY ASSEMBLY	12753	12754	12755	12756	12757	12758	12759
		SOCKET	12705	12706	12707	12708	12709	12710	12711
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780
	3/8	SOCKET ACCESSORY ASSEMBLY	12760	12761	12762	12763	12764	12765	12766
		SOCKET	12767	12768	12769	12770	12771	12772	12773
		JIFFY TIP 5/64 STALL	12774	12775	12776	12777	12778	12779	12780