


FOR SERIES 3 ATTACHMENTS

STALL FLUSH TYPE INSTALLATION




WRENCH TIP HEX CHART FOR
BREAK-AWAY FRANGIBLE COLLARS
FLUSH (NO SOCKET)



THE SOCKET HEX IS BUILT INTO THE GEAR
OF THE TOOL. NO SOCKET IS USED

JIFFY TIP



SOLID ONE PIECE

SERIES 3 FLUSH			
PIN HEX	3/32	1/8	5/32
JIFFY TIP STALL	13662	13663	13664