



# FOR SERIES 2 ATTACHMENTS

## TORQUE CONTROL INSTALLATION 5/64 WRENCH TIP



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	1/4	1/2	1	1 1/2	2	2 1/2	3
5/64	7/32	SOCKET ACCESSORY ASSEMBLY	12781	12782	12783	12784	12785	12786	12787
		SOCKET	12679	12680	12681	12682	12683	12684	12685
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829
	1/4	SOCKET ACCESSORY ASSEMBLY	12788	12789	12790	12791	12792	12793	12794
		SOCKET	12686	12687	14446	12688	12689	12690	12691
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829
	9/32	SOCKET ACCESSORY ASSEMBLY	12795	12796	12797	12798	12799	12800	12801
		SOCKET	12692	12693	12694	12695	12696	12697	12698
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829
	5/16	SOCKET ACCESSORY ASSEMBLY	12802	12803	12804	12805	12806	12807	12808
		SOCKET	12699	12700	14445	12701	12702	12703	12704
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829
	11/32	SOCKET ACCESSORY ASSEMBLY	12809	12810	12811	12812	12813	12814	12815
		SOCKET	12705	12706	12707	12708	12709	12710	12711
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829
	3/8	SOCKET ACCESSORY ASSEMBLY	12816	12817	12818	12819	12820	12821	12822
		SOCKET	12767	12768	12769	12770	12771	12772	12773
		JIFFY TIP 5/64 TORQUE	12823	12824	12825	12826	12827	12828	12829