



# FOR SERIES 3 ATTACHMENTS

## TORQUE CONTROL INSTALLATION 5/32 WRENCH TIP



FOR 12 POINT CONFIGURATION ADD X AFTER SOCKET OR SOCKET ACCESSORY ASSEMBLY NUMBER.

### LENGTH OF SOCKET

WRENCH TIP HEX	SOCKET HEX	DESCRIPTION	1/4	1/2	1	1 1/2	2	2 1/2	3
5/32	3/8	SOCKET ACCESSORY ASSEMBLY	13165	13166	13167	13168	13169	13170	13171
		SOCKET	13033	13034	13035	13036	13037	13038	13039
		JIFFY TIP 5/32 TORQUE	13179	13180	13181	13182	13183	13184	13185
	7/16	SOCKET ACCESSORY ASSEMBLY	13172	13173	13174	13175	13176	13177	13178
		SOCKET	13040	13041	13042	13043	13044	13045	13046
		JIFFY TIP 5/32 TORQUE	13179	13180	13181	13182	13183	13184	13185
	1/2	SOCKET ACCESSORY ASSEMBLY	13696	13697	13698	13699	13700	13701	13702
		SOCKET	13682	13683	13684	13685	13686	13687	13688
		JIFFY TIP 5/32 TORQUE	13179	13180	13181	13182	13183	13184	13185
	9/16	SOCKET ACCESSORY ASSEMBLY	15626	15627	15628	15629	15630	15631	15632
		SOCKET	15612	15613	15614	15615	15616	15617	15618
		JIFFY TIP 5/32 TORQUE	13179	13180	13181	13182	13183	13184	13185